



**Important – Please Read**




**DESCRIPTION**



## Important – Please Read

- Ⓐ Elbow bend fixation clip
- Ⓑ Elbow bend fixation
- Ⓒ Pipe fixation clip
- Ⓓ Pipe fixation
- Ⓔ Fixation screw and washer ( x4)
- Ⓕ Bowl fixing strip (x2), length 400mm
- Ⓖ Flexible sleeve (x 2)
- Ⓗ Bowl fixing kit
- Ⓙ Metal pegs (x6)
- Ⓚ Adjustable legs (x2)
- Ⓛ Punch screw
- Ⓜ Wall brackets (x2)
- Ⓝ Washer (x4)
- Ⓞ Wall screw (x4)
- Ⓟ Wall plugs (x4)
- Ⓠ Collar bidet (x1)

### ACCESSORIES (not supplied)



Evacuation kit elbow bend  
Evacuation kit straight

Ref. 92 4000-07  
Ref. 92 4010-07


#### Tools required:

- Set of keys from 8 to 19mm
- Metal saw
- Drill with a bit diameter 8mm
- Leveller
- Pencil & ruler
- Measuring tape
- Hammer
- Screwdriver

#### Advice:

- Keep this notice for any future maintenance
- ⚠ Read the instructions supplied with the bowl, the cover, the tank and the pressurised water supply system before starting installation work.


## TYPES OF INSTALLATION



① Fixed to a thin partition wall

② Built in to the rising column

## USEFUL MEASUREMENTS



I - Minimum depth of the frame = 140mm


II - Thickness of the cladding  
 $Y - 400 - 80 - x$  mm  
Or,  $x$  = thickness of the ceramics at the bowl fixation level  
This calculation does not take into account any constraints due to the tank or pressurised water supply.

III - Height : adjustable from 325 to 525mm


IV - Height of the bowl : 400mm (finished floor)

V - maximum thickness of the finished floor = 185mm



## I - ASSEMBLING THE BOWL FIXATION RODS



- 1 Measure the between-axis of the bowl (A)
- 2 Place the rods (f) in the holes in the frame corresponding to the between-axis and fix them in place with 2 nuts.





## II - ADJUSTING THE FRAME HEIGHT



- 1 Place the frame in its final position
  - 2 Unscrew the 4 nuts (k)
  - 3 Adjust the leg heights so that the top of the bowl is at about 400 mm from the finished floor
  - 4 Check that the frame is horizontally level, and screw the nuts back in.
- ⚠ If the frame is fixed onto a bare floor, the maximum thickness of the finished floor should not exceed 185 cm.


### III - PREPARING THE FIXATION




- 1 Mark the drilling points
- 2 Remove the frame and drill to a depth of 55 mm at maximum, using an 8 mm diameter drill bit for ground metal plugs. For wall plugs use a 10 mm diameter drill bit, and drill to a depth of 70 mm
- 3 Move the frame back in place, position the metal pegs (i) in the holes without any effort

**BOWL installation beginning page 6**  
**BIDET installation beginning page 12**


### IV - PREPARING THE BOWL WATER SUPPLY








- 1 Measure the diameter of the feeder pipe at the place where it will be attached to the fixation clip.
- 2 Put the fixation clip into place (b) using 2 screws and washers (e) and adjust the height according to the measured diameter. Marks are engraved on the clip to guide you.



## V - PREPARING THE BOWL EVACUATION CONNECTION




- 1 Measure the diameter of the evacuation pipe at the place where it will be attached to the fixation clip.
- 2 Attach the fixation clip using 2 screws and washers (e) and adjust the height according to the measured diameter. Marks are engraved on the clip to guide you.




## VI - PUTTING THE FRAME INTO PLACE



- 1 Put the frame into its final place and attach it with the metal pegs, they must be inserted into the holes without any effort.



## VII - CONNECTING THE WATER SUPPLY AND BOWL EVACUATION




- 1 Put the evacuation pipe into place
  - 2 Attach the pipe using the fixation clip (c)
  - 3 Put the elbow bend supply pipe into place
  - 4 Attach the elbo bend pipe using the fixation clip (a)
- ⚠ If you need to unclip, wing nuts are attached to the fixing clips to do this.






## VIII - WATER TRIALS



- ❶ Insert the water supply pipe and the evacuation pipe into the holes on the bowl.


- ❷ Place the bowl in the frame  
❸ Turn the water on and flush  
❹ Check that the arrival and evacuation pipes are sealed (watertight)  
❺ Take the bowl off again




Do the finishings if necessary

## X - CONNECTING THE BOWL


⚠ Read the instructions for the bowl and lid before starting.




❶ Using a ruler placed as in the drawing below, make a mark on the bowl side of the 2 supply pipes.



❷ Take the pipes off the bowl and insert them into the frame. Using a ruler placed as in the drawing below, make a mark on the wall side of the 2 pipes.



❸ For each of the pipes, measure the distance (L) between the 2 marks



❹ Carry over this measurement (L) and increase it by 3mm at the end (on the frame side) of each pipe. For example, if  $L = 50\text{mm}$ , shorten the pipe by 53mm


❺ Cut the pipes with a metal saw

❻ Smoothen the cuts with a file


❼ Measure the thickness of the back of the bowl (B)

❽ If necessary, cut the fixation rods (I) so that the part which sticks out from the wall is equal to  $(B) + 20\text{mm}$ .

❾ Shorten the flexible sleeves so that the part which sticks out from the wall is equal to  $(B) - 15\text{mm}$



## X - CONNECTING THE BOWL (continued)



## XI - ATTACHING THE BOWL

